

•

•

Quick dry

Easy application

**MPI** Approved

Washable

credit

Soap and water clean up

Eligible for LEED® v4

### Features

- Zero VOC
- Low odor
- Excellent hiding
- Great touch up
- Spatter resistant
- Decorative and uniform eggshell finish

### **Recommended For**

Interior wall and ceiling surfaces in commercial and institutional environments where an eggshell finish is desired. For use on primed or previously painted drywall, masonry, plaster, wood, metal and wallpapered surfaces.

# ULTRA SPEC<sup>®</sup> 500 INTERIOR EGGSHELL FINISH N538

# **General Description**

A professional-quality interior waterborne eggshell finish based on a proprietary cross-linking acrylic resin that tints on the Gennex<sup>®</sup> zero VOC colorant system. This waterborne interior eggshell provides a decorative scrubbable finish that is eligible for LEED<sup>®</sup> v4 credit and passes the most stringent environmental standards in any color. Because it tints on our Gennex<sup>®</sup> waterborne colorant system all Ultra Spec<sup>®</sup> 500 finishes are available in any color without an increase in VOC.

### Limitations

- Do not apply when air and surface temperatures are below 50 °F (10 °C)

Colors — Standard:				Technical Data◊	White	
White (01)				Vehicle Type	Acrylic Copolymer	
— Tint Bases:				Pigment Type	Titanium Dioxide	
Benjamin Moore <sup>®</sup> Gennex <sup>®</sup> bases 0X, 1X, 2X, 3X & 4X				Volume Solids	42 ± 2%	
— Special Colors: Contact your Benjamin Moore representative				Coverage per Gallon at Recommended Film Thickness 350 – 400 sq. ft		
Certifications & Qualifications:				Recommended Film	-Wet	4.3 mils
VOC compliant in all regulated areas				Thickness	– Dry	1.8 mil
Zero VOC Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84				Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint.		
ASTM E-84 Master Painters Institute MPI # # 52, 52 X- Green <sup>™</sup> , 145, 145 X-Green <sup>™</sup> Master Painters Institute High Performance # 139, 139 X-Green <sup>™</sup>			Dry Time @ 77 °F (25 °C) @ 50% RH	- To Touch2 Hours- To Recoat2 - 3 Hours		
Anti-microbial - T	0	intimicrobial additives t	Painted surfaces can be washed after two weeks. High humidity and cool temperatures will result in longer dry, recoat and service times.			
performance criteria regarding VOCs, emissions,				Dries By		Coalescenc
				Viscosity	95 ± 5 KU	
				Flash Point	N/A	
				Gloss / Sheen	Eggshell (20 – 25 @ 85°)	
application, washability, scrubbability and packaging, while also delivering the premium levels of performance you expect from Benjamin Moore.			Surface Temperature at	– Min.	50 °	
			Benjamin Moore.	Application	– Max.	90 °I
Eligible for LEED <sup>®</sup> v4 Credit	CDPH v1 Emissions Certified	Qualifies for CHPS low emitting credit (Collaborative for High Performance Schools)	VOC (in any color)	Thin With		See Cha
				Clean Up Thinner		Clean Wate
				Weight Per Gallon		10.8 lb:
YES	YES	YES	< 50 g/L	Storage Temperature	– Min.	40 °F
	published chemical res	ed by independent third triction and performance - <b>11 2015 standard</b>	•		– Max.	90 °F
Technical Assistance           Available through your local authorized independent Benjamin Moore retailer.           For the location of the retailer nearest you, call 1-866-708-9180 or visit           www.benjaminmoore.com				Volatile Organic Compounds (VOC)		
				0 Grams/Liter 0 Lbs./Gallon		
				Zero VOC post tint (	any base and a	וץ color)

 $\Diamond \mbox{Reported values are for White. Contact Benjamin Moore for values of other bases or color.$ 

# Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure 30 days before applying base coat. Cured plaster should be hard, have a slight sheen and maximum PH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

Difficult Substrates: Benjamin Moore offers a variety of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore® retailer can recommend the right problem-solving primer for your special needs.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSHapproved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

# **Primer/Finish Systems**

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results, tint the primer to the approximate shade of the finish coat, especially when a significant color change is desired. Special Note: Certain custom colors require a Deep Color Base Primer tinted to a special prescription formula to achieve the desired color. Consult your retailer or a Benjamin Moore representative.

### Wood, and engineered wood products:

Primer: Ultra Spec<sup>®</sup> 500 Interior Latex Primer (N534) or Fresh Start<sup>®</sup> Multi-Purpose Oil Based Primer (024)

Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538) Drywall:

Primer: Ultra Spec® 500 Interior Latex Primer (N534) or Fresh Start® Multi-Purpose Latex Primer (N023)

Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538) Plaster (Cured):

Primer: Ultra Spec<sup>®</sup> 500 Interior Latex Primer (N534) or Fresh Start<sup>®</sup> Multi-Purpose Latex Primer (N023)

Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538)

### Rough or Pitted Masonry:

Primer: Ultra Spec® Masonry Interior/Exterior Hi-Build Block Filler (571) Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538)

### **Smooth Poured or Precast Concrete:**

Primer: Ultra Spec® Masonry Interior / Exterior 100% Acrylic Masonry Sealer (608)

Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538) Ferrous Metal (Steel and Iron):

Primer: Ultra Spec® HP Acrylic Metal Primer (HP04) or Super Spec HP® Alkyd Metal Primer (P06)

Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538)

Non-Ferrous Metal (Galvanized & Aluminum): All new metal surfaces must be thoroughly cleaned with an Oil & Grease Emulsifier Corotech® V600 to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion

Primer: Ultra Spec® HP Acrylic Metal Primer (HP04)

Finish: 1 or 2 coats Ultra Spec® 500 Interior Eggshell Finish (N538)

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

# Application

Stir thoroughly before use. Apply one or two coats. For best results, use a Benjamin Moore® Professional custom-blended nylon/polyester brush, Benjamin Moore® Professional roller, or a similar product. This product can also be sprayed.

Conditioning with Benjamin Moore <sup>®</sup> 518 Extender may be necessary under certain conditions to adjust open time or spray characteristics. The chart below is for general guidance						
	Mild conditions	Severe conditions				
	Humid (RH> 50%) with no direct sunlight & with little to no wind	Dry (RH<50%), in direct sunlight, or windy conditions				
Brush: Nylon / Polyester		Add 518 Extender or water:				
Roller: Premium Quality 3/8" roller cover	No thinning necessary	Max of 8 fl. oz. to a gallon of paint				
<b>Spray: Airless</b> Pressure: 1500-2500 psi Tip: 0.013-0.017	,	Never add other paints or solvents.				

# Thinning/Clean up

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents.

Clean up: Use soap and water. Spray equipment should be given a final rinse with mineral spirits to prevent corrosion.

USE COMPLETELY OR DISPOSE OF PROPERLY. Drv emptv containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency on disposal options.

# **Environmental Health & Safety Information**

Use only with adequate ventilation. Do not breathe sprav mist or sanding dust. Ensure fresh air entry during application and drying. Avoid contact with eyes and prolonged or repeated contact with skin. Avoid exposure to dust and spray mist by wearing a NIOSH approved respirator during application, sanding and clean up. Follow respirator manufacturer's directions for respirator use. Close container after each use. Wash thoroughly after handling.

WARNING: Cancer and Reproductive Harmwww.P65warnings.ca.gov

WARNING: This product contains isothiazolinone compounds at levels of <0.1%. These substances are biocides commonly found in most paints and a variety of personal care products as a preservative. Certain individuals may be sensitive or allergic to these substances, even at low levels.

FIRST AID: In case of eye contact, flush immediately with plenty of water for at least 15 minutes; for skin, wash thoroughly with soap and water. If symptoms persist, seek medical attention. If you experience difficulty breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical attention immediately.

IN CASE OF SPILL - Absorb with inert material and dispose of as specified under "Clean up".

## **KEEP OUT OF REACH OF CHILDREN** PROTECT FROM FREEZING

Refer to Safety Data Sheet for additional health and safety information.

Benjamin Moore & Co., 101 Paragon Drive, Montvale, NJ 07645 Tel: (201) 573-9600 Fax: (201) 573-9046 www.benjaminmoore.com M72 N538 US 072820 Benjamin Moore, Fresh Start, Gennex, Green Promise, Super Spec HP, Ultra Spec and the triangle "M" symbol are registered trademarks, licensed to Benjamin Moore & Co. All other marks belong to their respective owners. ©2015, 2020 Benjamin Moore & Co. All rights reserved